PREHEAT YOUR OVEN TO 325 degrees PREHEAT YOUR OVEN TO 325 degrees PLOCE THIS MIX IN O LOW OND ODD :: PLOCE THIS MIX IN O LOW! ON A Odd ... - 3/4 (UP Shortening - 3/4 CUP Shortening - 1/3 CUP WOHER - 1/3 (UP WOTER - 2 TSP VONIIIO EXTRACT - 2 TSP VONILLA EXTRACT MIX together well, toking core to stir with MIX together well toking core to stir with a spoon so as not to crush the chocolate a spoon so as not to crush the chocolate Chips or the peoply butter cups Chips or the peoplet butter cups. BOKE 12-15 MINUTES THEN ENIOYI BOKE 12-15 MINUTES THEN ENIOYI PREHEAT YOUR OVEN TO 325 degrees PREHEAT YOUR OVEN TO 325 degrees PLOCE this mix in a bowl and add ... PLOCE THIS MIX IN O LOW! OND ODD ... - 3/4 CUP Shortening - 3/4 CUP Shortening - 1/3 CUP WOTER - 1/3 (UP WOTER - 2 TSP VONIIIO EXTROCT - 2 TSP VONIIIO EXTROCT MIX together well, toking core to stir with MIX together well, toking core to stir with O SPOON SO OS NOT TO CRUSH THE CHOCOLOTE a spoon so as not to crush the chocolate Chips or the peoplet butter cups Chips or the peoplet butter cups. BOKE 12-15 MINUTES THEN ENIOYI BOKE 12-15 MINUTES THEN ENIOYI